

The following glossary is a list of terms commonly used in the trade in Alberta and elsewhere in Canada. Individuals preparing for examinations should be familiar with these terms and how they are used in the context of the trade.

BTU's
Delta
Emery Cloth
Fault interrupter
Hermetic
Jewelers rouge
LPG
MSDS
Photo-electric cell
Polyalkylene glycol base
Polyethylene base
Polymer base
Pyrometer
Shunt
Swaging tool
Thermocouple
Wye
Zener diode