

The following glossary is a list of terms commonly used in the trade in Alberta and elsewhere in Canada. Individuals preparing for examinations should be familiar with these terms and how they are used in the context of the trade.

ASA	KN	Sag rod
Anchor bolts	Kerf	Shear
Auxiliary view	KI	Sx
Bill of material	KN	Tie bolts
CSA	Ksi	Transmittals
Block	Lien	Theodolite
Bracing	Moment	Unshaded
Centroid	Mpa	Weldable
Centroidal	NISD	WF
Connections	Purlin	Workpoints
Detailing	PDF	
Dimscale	Pedway	
Doubler	Precast	
Ddm	Psi	
Equilibrant	QA	
Fabrication drawing	QC	
Gage (gauge)	RFI	
Girder	RFP	
Girt		
HSS		
ISO		
Interia		